

WARRANTY

All Willow + Rose products carry a one year limited warranty from date of purchase. Visit willow-rosehome.com for warranty details and instructions.

CAUTION

Read all instructions before using this product and keep them for future reference.

- Do not use the product if it has been dropped, punctured, or damaged.
- Only use this product as intended.
- This product is for indoor use only, Do not use outdoors.
- Do not expose the product to direct sunlight, fire, or use near flames.
- Do not submerge the product in water
- Use soft cloth to clean. Do not use any corrosive cleaners/oils.
- This product contains small part that can pose a choking hazard if removed.
- This product is not a toy, keep it away from reach of children.

Note: Lithium-ion batteries will self discharge over time, and it is normal for battery performance to decline after several years of usage. To ensure battery life, do not store the product in an uncharged state for a length of time. If left in a discharged state for too long a lithium-ion battery will no longer have the ability to be recharged.

THIS PRODUCT IS NOT A TOY. DO NOT ALLOW CHILDREN TO PLAY WITH THIS PRODUCT

FCC STATEMENT

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

willow+rose

Soft Touch Bulldog Nightlight

USER MANUAL

WR-QL1206

WHAT'S INCLUDED

- Soft Touch Bulldog Night Light
- USB A to USB C Cable
- User Manual

**Power adapter not included*

GENERAL CARE

- To preserve luster, dust weekly to prevent grime from building up.
- Make sure the nightlight is turned off if the product is not in use.
- Recommended to at least fully charge once every 30 days to avoid battery idleness.
- Store in a cool, dry location in original package.

GETTING STARTED

The Night Light comes with a USB-A to USB-C cable that can be used to charge the light. To use the USB cable:

- Locate the USB-C port of the Night Light.
- Connect the included USB-C cable to the Night Light's USB-C port.
- Connect the USB-A cable end to an appropriate power adapter (not included).
- Plug the power adapter into a standard wall outlet.

OPERATIONS

Before operating your Night Light for the first time, make sure the light is fully charged. The Night Light has a red-light indicator that shows there is power reaching the product, and it is actively being charged. Once the light is fully charged the red-light indicator will turn green.

To operate the Night Light, locate the single power button on the bottom base of the Night Light.

POWER ON/OFF: Single-press the button to power on/off the Night Light.

TAP OPERATION AND CHANGING THE LIGHTING MODE

Note: Once the Night Light is powered by utilizing the power button on the bottom base, the Night Light can be fully operated using a swift and firm tapping motion including turning the light on or off. To ensure that the Night Light is completely off and inoperable, single-press the button located at the bottom base of the Night Light.

TAP POWER ON/ OFF

Utilizing two fingers, swiftly and firmly double-tap the top end of the Night Light to turn on/off the light.

CHANGING THE LIGHTING MODE

Once the Night Light is powered on it will be in low brightness warm-white mode. To change the lighting mode:

- Utilizing two fingers swiftly and firmly single-tap the top end of the Night Light to access high brightness warm-white.
- Utilizing two fingers swiftly and firmly, single-tap the top end of the Night Light once more to access the RGB colors.

- To lock-in a steady color of your choice, utilizing two fingers swiftly and firmly, single-tap the top end of the Night Light once.
- To go back to the automatic breathing rainbow colors, utilizing two fingers swiftly and firmly, single-tap the top end of the Night Light once more.

Note: To go back to the warm-white lighting modes, double-tap the Night Light to power off and double-tap once more to power back on low brightness warm-white mode.

30-MINUTE TIMER

After setting your Night Light to the desired color mode, you can set a 30-minute timer to turn off the Night Light automatically.

To enter a 30-minute timer:

- Locate the power button on the bottom base.
- Press and hold the power button until you see the Night Light blink once.

Note: If you change the Night Light's color mode after setting the timer, the timer will reset and will no longer turn off automatically.

SPECIFICATIONS

Input: 5V/1A

Battery Capacity: 800mAh

LED Colors: Low brightness warm white, high brightness warm white, and RGB colors